

Make	Model	Year	Submodel	Variant	Engine
Toyota	Land Cruiser	2007	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2007	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2007	HZJ105 SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2006	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2006	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2006	HZJ105 SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2005	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2005	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2005	HZJ105 SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2004	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2004	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2004	HZJ105 SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2003	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2003	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2003	HZJ105 SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2002	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2002	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2002	HZJ105 SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2001	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2001	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)

Make	Model	Year	Submodel	Variant	Engine
Toyota	Land Cruiser	2001	HZJ105 SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2000	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2000	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	2000	HZJ105 SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1999	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1999	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1999	HZJ105 SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1998	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1998	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1998	HZJ80 SUV 4.2 D	AWD Diesel 4.2L 6cyl 99kW 1H-Z	4164cc 99kW (Diesel)
Toyota	Land Cruiser	1998	HZJ105 SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1997	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1997	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1997	HZJ80 SUV 4.2 D	AWD Diesel 4.2L 6cyl 99kW 1H-Z	4164cc 99kW (Diesel)
Toyota	Land Cruiser	1996	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1996	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1996	HZJ80 SUV 4.2 D	AWD Diesel 4.2L 6cyl 99kW 1H-Z	4164cc 99kW (Diesel)
Toyota	Land Cruiser	1995	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1995	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1995	HZJ80 SUV 4.2 D	AWD Diesel 4.2L 6cyl 99kW 1H-Z	4164cc 99kW (Diesel)

Make	Model	Year	Submodel	Variant	Engine
Toyota	Land Cruiser	1994	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1994	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1994	HZJ80 SUV 4.2 D	AWD Diesel 4.2L 6cyl 99kW 1H-Z	4164cc 99kW (Diesel)
Toyota	Land Cruiser	1993	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1993	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1993	HZJ80 SUV 4.2 D	AWD Diesel 4.2L 6cyl 99kW 1H-Z	4164cc 99kW (Diesel)
Toyota	Land Cruiser	1992	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1992	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1992	HZJ80 SUV 4.2 D	AWD Diesel 4.2L 6cyl 99kW 1H-Z	4164cc 99kW (Diesel)
Toyota	Land Cruiser	1991	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1991	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1991	HZJ80 SUV 4.2 D	AWD Diesel 4.2L 6cyl 99kW 1H-Z	4164cc 99kW (Diesel)
Toyota	Land Cruiser	1990	HZJ70RV,HZJ75RV,HZJ78R SUV 4.2 D	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1990	HZJ75RP,HZJ79R Pickup 4.2 D 4x4	AWD Diesel 4.2L 6cyl 96kW 1H-Z	4164cc 96kW (Diesel)
Toyota	Land Cruiser	1990	HZJ80 SUV 4.2 D	AWD Diesel 4.2L 6cyl 99kW 1H-Z	4164cc 99kW (Diesel)